



Center to Center - Chart
Rectangular Offset Handles

Handle Size	Mounting Holes
13.5 Inches	12 Inches
16 Inches	14.5 Inches
18 Inches	16.5 Inches
24 Inches	22.5 Inches
36 Inches	34.5 Inches
48 Inches	46.5 Inches
60 Inches	58.5 Inches
72 Inches	70.5 Inches

1. Drill holes at required center to center location (1/2" Diameter Hole)
2. Insert the bolt through the push side of the door to the pull side.
3. Tighten the outside pull with the bolts. Make sure the pull is properly tightened and snug to the door face. The bolts should be rigid before proceeding.
4. Slide the inside pull over the bolt and hold the inside pull tight to the face of the door while tightening the set screw.

Note: It is imperative that the set screws are firmly tightened and that the door pull is tight against the door face so that the set screw properly engages the head of screw.