



Center to Center - Chart	
Ladder Style Handles	
Handle Size	Mounting Holes
12 Inches	6 Inches
16 Inches	10 Inches
18 Inches	12 Inches
24 Inches	18 Inches
32 Inches	26 Inches
36 Inches	30 Inches
48 Inches	42 Inches
60 Inches	54 Inches
72 Inches	66 Inches

1. Drill holes at required center to center location (1/2" Diameter Hole)
2. Insert the bolt through the push side of the door to the pull side.
3. Tighten the outside pull with the bolts. Make sure the pull is properly tightened and snug to the door face. The bolts should be rigid before proceeding.
4. Slide the inside pull over the bolt and hold the inside pull tight to the face of the door while tightening the set screw.

Note: It is imperative that the set screws are firmly tightned and that the door pull is tight against the door face so that the set screw properly engages the dead of screw.